

Introduction	1
Part I Introduction of Huawei	
Huawei အကြောင်းသိမှတ်ဖွယ်ရာများ	3
Part II Concepts & Facts	
မသုံးမဖြစ်သော Huawei Mobile Tip များ	10
Tip 1 Install Huawei Driver	10
Tip 2 Enable USB Debugging	13
Tip 3 Fastboot Mode	16
Tip 4 Recovery Mode	18
Tip 5 Firmware Flashing Mode	20
Part III Features, Specifications & Root	
Huawei Ascend D2	22
Huawei Ascend G510 (U8951 / T8951)	27
Huawei Ascend G520	45
Huawei Ascend Mate (MT1-U06)	60
Huawei Ascend P2 (P2-6011)	63
Huawei Ascend Y300 (U8833 / T8333)	67
Huawei Ascend G600 (U8950D / C8950D / T8950D)	82
Huawei Boulder (U8350)	93
Huawei Honor (U8860)	96
Huawei Ideos (U8150)	101
Huawei Ideos X3 (U8510)	104
Huawei Ideos X5 (U8800 / C8800)	106
Huawei Sonic (U8650 / C8650)	109
Huawei U8100	112
Huawei U8110	114
Huawei U8220	117
Huawei U8300	119
Huawei Vision (U8850)	122
Huawei Ascend D1 Quad (U9510)	126
Huawei Ascend G300 (U8815 / C8815 / U8818)	129
Huawei Ascend P1/P1S (U9200 / T9200)	141
Huawei Ascend Y200 (U8655)	147
Huawei U8652	151

Huawei Ascend P6 (P6 U00 / P6 U06 / P6 T00)	155
Huawei Honor 2 (U9508)	162
Huawei Ascend G330 (U8825D / C8825D)	169
Huawei Ascend D1 (U9500)	179
Huawei Ideos X6 (U9000)	183
Huawei U8500 / C8500 / C8500S	186
Huawei C8600 / T8600	189
Huawei Sonic+ (U8661)	191
Huawei Deuce (U8520)	197
Huawei Fusion 2 (U8665)	200
Huawei Ascend G500 (U8836D)	204
Huawei U8830PRO / T8830PRO	207
Huawei Ascend Y200T (T8620)	210
Huawei Ascend Y210 (U8685D / C8685D / T8685D)	213
Huawei Ascend Y300C (C8833)	225
Huawei Ascend Y220T	231
Huawei Ascend Y310	236
Huawei Ascend C8813 / C8813D / C8813Q	242
Huawei Ascend Y320/ Y320C / Y320T	249
Huawei Ascend G700	258
Huawei Ascend G610 / G610S / G610C	261
Huawei Ascend G525	271
Huawei Ascend G606	275
Huawei Ascend C8812 / C8812D / C8812E	279

PART IV Installing Myanmar Font & Essential Tips	
Installing Myanmar Font	293
Essential Tips for MPT	304

PART V Huawei Firmware Flashing	
With SD Card	308
With Flash Tool	310

Conclusion	314
-------------------	-----